Anytruck Portal Quick Start

Guide

Version 3.0

AnyTrućk[™]

Introduction

- Main screen
- Location screen
- Information panel
- Route screen
- Share Location
- Park alarm
- History trail
- Group Tracker column
- Edit Tracker settings
- Device manager
- User manager



البيكية والتبيا

Don't have an account? Sign up




Introduction

Go to <u>truck.anytrek.com</u> to login.

Login to the site using your user name and password to access your account.

The same user name and password can be used to log into the Anytrek smartphone apps.



The Anytruck web portal is the 'engine room' where you can configure and view all your Anytrek trackers, see history trails, setup maintenance reminders, define 'Park' zones and enhance your customer service by allowing your customers to view their delivery in real time.






Download the app for your phone type by clicking on the logos above


Main screen

This is the opening view. From this screen you can see all your trackers and their current status as well as perform a number of functions.




Details and actions for selected tracker

Location screen




Information Panel


The information panel for the current tracker is accessed by clicking on the tracker icon in the main map screen. It contains 3 separate panels shown below. Each panel provides the ability via the drop down boxes to access the history trail and trip report data for the tracker.



Shows the current location, status, speed, battery status and last report time.




Shows the operating information of the tracker including details f the vehicle and driver (if entered).



Provides the ability to plan alternate routes to new destinations from the current location.


Route screen


This function will provide the best route from the current location to a new destination.



Share Location screen

Allows you provide your customers with limited access to the portal to view the movement of their cargo.






This is the view your customer will see when they open the URL.


Park Alarm screen

Use this function to set GeoFence areas for the current tracker or for all your trackers.



Click and hold on one of the white dots to change the size of the GeoFence. The minimum radius is 1,000 ft and the maximum is 1 mile.


Hold the right mouse button down and drag the center of the GeoFence to the desired location.



When the tracker leaves the GeoFence, an SMS alert will be sent to the nominated cell number and a flashing icon as shown above will display on the main screen.


History Trail screen

This function allows you to replay any trip for any of your trackers.



Click to open the drop-up menu and select the required time period.

Detailed breakdown of the trip showing the different status of Idling, Parked, and Stopped as well as time and distance covered.




Click on the arrow to replay the trip.

Show Points will display every location report received during the trip. Focus on the Device will keep the tracker's location in the center of the screen as the trip is replayed.

Click to open the drop-down menu to select different time periods for each of the statuses. The map and report will update to reflect the new values.

Group Tracker column

Create sub-accounts. Reallocate trackers. Change tracker details. Set maintenance reminders. Send tracking screens to customers.



Groups


The trackers can be organised into groups, and the groups exist under the Company as defined by the user. Groups can be used to reflect fleets, routes, locations, vehicle types etc.

Each account is created with a group named Default. To add groups, click on the +New at the top of the column.



Enter the new group name and assign a numeric weight to determine the sequence the groups will be displayed in the column. A weight of 10 will display above a group with a weight of 9.

Clicking on any other group name will display 2 icons; the first one allows you to change the name of the group and the second one deletes the group. Note that a group cannot be deleted if it contains trackers.



Individual trackers can be moved to any other group. To do this, select the tracker to be moved and left click on it and hold the mouse button down.

Move the pointer and the groups will compact to show only the group name.


Move the pointer and tracker onto the new group (the window attached to the pointer should turn green) and release the mouse button to reallocate the tracker to the new group.

The account hierarchy is as follows;

- -The Company is the parent and owner of the account. From here, all the trackers owned by this account can be viewed and accessed.
- -The Group setting is used to allocate trackers to different operating divisions, branches, locations etc. The admin user can create user logins for each Group which permits that user to only see the trackers in their group.

Edit Tracker settings

Click on a tracker to view more info. Each of the 3 green icons performs a different task.




Generate a limited time session for a customer to be able to view the route and progress of their cargo.

Device Manager

Provides control over company information, tracking devices and users.

Summary screen






Device Manager

This tab provides a listing of all the trackers allocated to this account, and displays a number of data values.

Device Manager User Center Logout AB Layer AB ON QC -

Device Manager screen



Select multiple tracker to move to a different company.

User Manager

This is where new users are created and edited. Only admin level users have access to these functions. Each account must have at least 1 admin level account and there are no limits on the number of user accounts that can be defined. Users can exist in more than one sub company at a time. This may be useful for financial controllers, operational controllers or anyone that requires visibility across the entire (or part) of the fleet.



									8
Company List	Summa	ry Device Manag	ger User manage	er					
Oz Trucking - AAMI - ILS_Aus - Jim - Kim	Keyword: Username/Cellphone/Email Including deleted Directly Search								Add
		Affiliated	Username	Cellphone	Email	Status	Created Date	Operation	
	_ 1	Oz Trucking	mario_admin		mario@anytrek.c om	Administrator	08-17 19:15	Edit Preference Bind Device Logging Dele	ete .
Laser NRMA	2	Oz Trucking	mario			Admin User View	09-19 14:25	Edit Preference Bind Device Logging Dele	ete .
- Pat	3	Laser	Laser			Administrator	05-24 13:43	Edit Preference Bind Device Logging Dele	ete .
Snap	4	Kim	Kim			Admin User View	09-12 08:41	Edit Preference Bind Device Logging Dele	ete .
	1 - 4 of 4 items			20 :	20 50 100 500 2000				H ← 1 → H ↑
	Modify user preference								

Add new users to your account.
To add users to sub-companies
first highlight the selected
company in the left hand column
and then click on Add

	8
Username:	
type:	Admin User View ▼
Change password:	✓
New Password:	
Confirm Password:	
Cellphone:	
Email:	
status:	Normal •
	Save

The user name will be the logon ID. Normal permissions prevent changes to accounts, while admin has full edit capability.